

SmartCell

Intelligent Wireless Zone Monitor

Quick Start Guide

Contents

Introduction	3	Set time & date	17
Important notes	3	Install devices	18
Additional documentation	4	Add devices to system	19
Overview of system setup	5	Device attributes	20
What's in the box	7	Device location text	22
WZM features	8	Text entry	23
Side cover removal	8	Set the panel type	24
Open WZM	9	Sounder tones	25
Optional door removal	9	Sounder duration	27
Cable entry	10	Sounder activation method	28
Fix WZM to wall	10	Pulsed output	29
Addressable fire system wiring	11	Device indicator operation	31
Conventional fire system wiring	12	Device signal levels	32
Mains power connections	13	Test devices	33
24 VDC power connections	13	Congratulations	36
Re-fit door	14		
Connect backup battery	14		
Remove 3V battery tab	15		
Apply power	15		
Engineer menu entry	16		

Introduction

This quick start guide will show you how to set up the SmartCell Wireless Zone Monitor (WZM), for connection to either addressable or conventional fire alarm systems. For advanced programming, refer to the 'SmartCell Wireless Zone Monitor Programming Guide' (MK067).

Note: this quick start guide will cover the method of adding devices via power-up. Refer to the programming guide for more information of alternative methods.

Important notes



The installation must conform to applicable local installation codes and should only be installed by a fully trained competent person.




Always select an appropriate device type for the application as per local codes of practice, or as advised by a qualified professional.



The procedures outlined in this installation guide must be carefully followed.



SmartCell devices contain electronics that may be susceptible to damage from Electro Static Discharge (ESD). Take appropriate precautions when handling electronic boards.



To ensure correct operation, products must be used within the specified environmental operating conditions.

Additional documentation

The below QR codes provide links to the a wide range of WZM information, including:

- Wireless Zone Monitor Programming Guide (MK067)
-
- Wireless Zone Monitor Installation Guide (TSD127)
-
- Wireless Zone Monitor Datasheet
-
- Wireless Zone Monitor certification

Wireless Zone Monitor
(230 VAC version)



https://firesecurityproducts.com/en/product/fire/SC_13_1100_0001_99/83586

Wireless Zone Monitor
(24 VDC version)



https://firesecurityproducts.com/en/product/fire/SC_13_2100_0001_99/83591

Overview of system setup

Step 1


Install the SmartCell WZM.

Step 2

Log on devices required for the installation - Smoke detectors, heat detectors, call points, sounders and input / output devices, etc.

Enter device location text.

Note: If devices and zones are not programmed with custom text labelling, default text will be displayed. E.g.



```
Z01 A04          TAMPER
Sounder Detector
ID:001234
                        View>
```

*Example device fault with
default device text:*

Step 3

Change device default settings if required in accordance with local codes of practice, or as professionally advised.

Step 4

Set the WZM to match the connected fire control panel type (either conventional or addressable).

Step 5

Configure sounder tones, durations and activation methods.

Step 6

Check all device signal levels are stated as 'GOOD'.

Step 7

Test every device for correct operation, using appropriate test equipment.

Note: sounders may activate upon activation of a wireless device if the 'Sounder activation method' is set to 'Immediate'.


Step 8

Weekly test the system in accordance with local codes of practice.


Step 9

Maintain the system in accordance with local codes of practice and manufacturers recommendations.


What's in the box




SmartCell WZM




Right hand side cover




6V 4 Ah battery



WZM fixing template



Resistor pack




Log on magnet




Allen key

WZM features




Side cover removal


The following steps illustrate how to remove the side covers:



Slide the side cover sideways, creating a gap as shown.




Position your fingers behind the cover's protruding edge.




Press the cover's releasing clip with your thumb (A), and simultaneously rotate the side cover anti-clockwise (B), as viewed overhead to remove the cover.

Open WZM


1. Unclip side cover.



2. Loosen screws.



3. Open door.




Refer to the 'Side cover removal' section (page 8) for details.

230 VAC variant shown


Optional door removal

Disconnect the ribbon cable, then turn and release the door hinges.


1.




2.



3.




4.



Cable entry


Select cable entry points as required, before fitting to the wall.

Rear side view



**NO CABLE ACCESS
AT THE TOP OF THE
UNIT!**

Under side view



 = Available entry point


Fix WZM to wall

Key hole

Spirit level

Fixing
positions

Fixing
positions




Note: the supplied back box mounting template can be used to drill the fixing positions.

Addressable fire system wiring

SKIP THIS STEP IF CONNECTING TO A CONVENTIONAL FIRE SYSTEM.

- Wire the inputs as shown below, using the resistor pack provided.
- If an input is not being used, leave the 20 kΩ resistor as factory fitted.
- Both outputs are voltage free and rated 30 V @ 1 A.
- The maximum cable length to connected devices is 10 m.



Addressable fire system connections

FOOTNOTES


- ★ Optional cabling, required only when the following SmartCell devices are added to the WZM; detectors, call points and I/O units (I/O units when set to 'Off When Reset') - see the SmartCell WZM Programming Guide (MK067) for more details on this feature.

† Wiring can be normally open or normally closed operation as required.

Conventional fire system wiring

SKIP THIS STEP IF CONNECTING TO AN ADDRESSABLE FIRE SYSTEM.

- The WZM must be connected to a dedicated zone and sounder output.
- The maximum cable length to connected devices is 10 m.




Conventional fire system connections

FOOTNOTES

- ★ Ensure that the manufacturer's specified end of line components and triggering resistors are fitted. See the control panel's instructions for more information.

Mains power connections

230 VAC WZMs only.




24 VDC power connections

24 VDC WZMs only.


The 24 VDC SmartCell WZM is designed to be powered from 2x 24 VDC power sources, to meet country specific requirements.

- Connect both power inputs.
- There are also general fault inputs (GEN FAULT) and mains fault (M FAULT) available.
- The fault inputs are NC and voltage free.
- If a fault input (GEN FAULT or M FAULT) is not being used, leave the link as factory fitted.




Re-fit door

230 VAC Re-connect the ribbon cable and re-fit the door hinges.




Connect backup battery

230 VAC WZMs only.




Remove 3V battery tab




Apply power

The power supply to the WZM can now be switched on.



Note: If mains supply is unavailable at this point, the WZM can be temporarily powered by the back-up battery.

To achieve this, simply press the PSU's 'START' button.



Engineer menu entry

The following steps are required to access the engineer menu (access level 3).

With the SmartCell WZM in its normal state the screen will display:

```
SmartCell WZM  
  
System Normal  
14:18           Access ✓
```

Press the (✓) button and the screen will display:

```
For Access  
Enter Code: _  
  
Press ✓ To Complete
```

Enter the engineer PIN code (default '333333'), then press the (✓) button to confirm. The screen will display:

```
* Welcome Service *  
Access Level 3  
Now Available  
All Buttons Active
```

Followed by:


```
*View System Status  
Maintenance/Test  
Device Options  
WZM Settines  ⏏
```

All engineer menus are now available. You can now:


- Set the time & date
- Configure the WZM
- Program devices to the system
- Enter device text
- Configure devices, i.e. device sensitivities, sounder tones etc.

Set time & date


From access level 3 (as previously shown on page 16), press the  button until the screen displays:




Press the  button and the screen will display:




Press the  button once. The screen will display:



Press the  button and the screen will display:



Press the  button and the screen will display:



To change the time, press the  button and the screen will display:

The following buttons are required to set the time:




Button(s)	Action
 	Increases and decreases the selected value.
 	Moves the cursor between the hour and minute selections.
	Saves the changes and returns to the previous screen.



Note: the same process is used for changing the date.

Install devices



Note: Refer to the associated device installation guide for full details.

Add devices to system

From access level 3 (*as previously shown on page 16*), press the  button until the screen displays:

```
View System Status
Maintenance/Test
Device Options
→WZM Settines  ⏏
```

Press the  button and the screen will display:

```
→Add New Device
Remove Device
Edit Settines
Signal Level Test  ⏏
```

Press the  button and the screen will display*:

```
→At WZM
At Device Location
Configure Devices  ⏏
```

Press the  button and the screen will display:

```
Insert Batteries
Into Device
NOW
```

Insert the device's batteries and the screen will change to show:

```
Add Fire Device ?
Sounder Detector
ID:001234
✓Add                <Exit
```

Check that the device ident on-screen matches the device ident shown on the barcode label. Press  to confirm, or  to cancel. If accepted, the screen will display:

```
New FIRE
Device Added
ID:001234
Address 01
```

Followed by:

Either continue adding new devices (by inserting batteries, or press  until the front screen is displayed.

```
Add Another
Device ?
✓Continue          <Exit
```

* Refer to the 'SmartCell Intelligent Wireless Zone Monitor Programming Guide' (MK067) for alternative programming methods.

Device attributes

From access level 3 (*as previously shown on page 16*), press the  button until the screen displays:

```
View System Status
Maintenance/Test
→Device Options
WZM Settings ◇
```

Press the  button and the screen will display:

```
→Add New Device
Remove Device
Edit Settings
Signal Level Test ◇
```

Press the  button until the screen displays:

```
Add New Device
Remove Device
→Edit Settings
Signal Level Test ◇
```

Press the  button and the screen will display:

```
A01 ID:001234
Sounder Detector
ID:001234
Devices ◇ Change>
```

Press the  button until the device to configure is shown. Press the  button and the screen will display:

```
A03 ID:001236
Sounder Detector
Beacon ID:001236
Devices ◇ Change>
```

Press the  button and the screen will display:

```
→Text Description
Detection- Dual
Smoke Sen- Normal
Heat Sen- 58C S ◇
```

Available options for each device type are shown overleaf.

Menu selection	Available options
Text Description	Refer to the 'Device location text' section overleaf.
Detection	Detection selection of 'Dual' (smoke & heat), 'Smoke Only' or 'Heat Only'.
Smoke Sen	Smoke sensitivity selection of; 'Normal*†' and 'Normal + AVF'. The AVF option allows additional verification of the alarm condition before reporting.
Heat Sen	Heat sensitivity selection of; '58 °C static*†', '58 °C rate of rise*', '72 °C static*', '72 °C rate of rise*'. * = 10 min
Sound Volume	Allows device sounder levels of; 'High' or 'Low'.
Self Sound	When enabled, the device will sound upon local alarm detection, whilst wireless communication with the WZM is lost.
Audio/Visual	Allows device sounder and beacon selection of; sounder & beacon, sounder only and beacon only.
O/P 1 OFF	Choose to switch the device's 'Output 1' off, when either the 'silence' or 'reset' button is pressed.
O/P 2 OFF	Choose to switch the device's 'Output 2' off, when either the 'silence' or 'reset' button is pressed.

Device location text

From access level 3 (*as previously shown on page 16*), press the  button until the screen displays:

```
View System Status
Maintenance/Test
→Device Options
WZM Settines  ◊
```

Press the  button and the screen will display:

```
→Add New Device
Remove Device
Edit Settines
Signal Level Test  ◊
```

Press the  button until the screen displays:

```
Add New Device
Remove Device
→Edit Settines
Signal Level Test  ◊
```

Press the  button and the screen will display the first device logged on to the system:

```
AD1          ID:001234
Sounder Detector
ID:001234
Devices◊      Change>
```

Press the  button to scroll through the devices until the required device is shown. Press the  button:

```
AD2          ID:001235
Dual Detector
ID:001235
Devices◊      Change>
```

Press the  button and the screen will display:

```
→Text Description
Detection-      Dual
Smoke Sen-      Normal
Heat Sen-       58C S ◊
```

Press the  button and the screen will display:

```
■Dual Detector
ID:001235

F1 ABC  F2 Delete
```

Refer to the ‘Text entry’ section overleaf.

Text entry

The following buttons will be required to enter new text descriptions:

Button	Action
	Moves the selected character through the alphabet (forwards), one character at a time.
	Moves the selected character through the alphabet (backwards), one character at a time.
	Moves the cursor (selected character) left, one character at a time.
	Moves the cursor (selected character) right, one character at a time.
FUNCTION 1 	Used to toggle character entry format between; upper case, lower case and number.
FUNCTION 2 	Provides a delete function; press for single character deletion, or press and hold to delete all text.
	Exits from the current screen. The user is asked whether to save the changes ( button for yes and  button for no).

Set the panel type

Default panel type is 'Conventional'. If the WZM is to be connected to an addressable type fire panel, follow the steps below:

From access level 3 (*as previously shown on page 16*), press the  button until the screen displays:

```
View System Status
Maintenance/Test
Device Options
→WZM Settings
```

Press the  button and the screen will display:

```
→Panel Type
Sounder Options
Device Indicator
```

Press the  button and the screen will display:

```
→Conventional ✓
Addressable
```

Press the  button and the screen will display:

```
Conventional ✓
→Addressable
```

Press the  button and the screen will display:

```
→Addressable Panel
Selected
```

Sounder tones

The default fire tone is TONE 5. Available tones are shown overleaf. To change the fire tone, follow the steps below:

From access level 3 (*as previously shown on page 16*), press the  button until the screen displays:

Press the  button and the screen will display:

Press the  button until the screen displays:

Press the  button and the screen will display:

Press the  button and the screen will display the currently selected tone:

Press the  button and the screen will display:

Press the  and  buttons to view the available tones and press the  button to select the required tone:

```

View System Status
Maintenance/Test
Device Options
→ WZM Settings

```

→ Panel Type
Sounder Options
Device Indicator

Panel Type
→ Sounder Options
Device Indicator

```
→Default Tone Select
   Sounder Duration
   Sounder Activation
   Pulsed Output      ◇
```




→Fire Tone - 05

```

970Hz - 630Hz, @1Hz
  05
Type 0      ✓ To Select

```

```
800Hz - 970Hz, @1Hz
  1 1 1 1
03
Type      / To Select
```

TONE	TONE TYPE	TONE DESCRIPTION / APPLICATION
1.		970Hz
2.		800Hz/970Hz at 2Hz
3.		800Hz - 970Hz at 1Hz
4.		970Hz 1s OFF / 1s ON
5.		970Hz, 0.5s / 630Hz at 1 Hz **Default fire tone**
6.		554Hz, 0.1s / 440Hz, 0.4s (AFNOR NF S 32 001)
7.		500 - 1200Hz, 3.5s / 0.5s OFF (NEN 2575:2000 Dutch slow whoop)
8.		420Hz 0.6s ON / 0.6s OFF (Australia AS1670 Alert tone)
9.		1000 - 2500Hz, 0.5s/ 0.5s OFF x 3/1.5s OFF (AS1670 Evacuation)
10.		550Hz / 440Hz at 0.5Hz
11.		970Hz, 0.5s ON / 0.5s OFF x 3 / 1.5s OFF (ISO 8201)
12.		2850Hz, 0.5s ON / 0.5s OFF x 3 / 1.5s OFF (ISO 8201)
13.		1200Hz - 500Hz at 1Hz (DIN 33 404)
14.		400Hz
15.		550Hz, 0.7s / 1000Hz, 0.33s
16.		1500Hz - 2700Hz at 3Hz
17.		750Hz
18.		2400Hz
19.		660Hz
20.		660Hz 1.8s ON / 1.8s OFF
21.		660Hz 0.15s ON / 0.15s OFF
22.		510Hz, 0.2s / 610Hz, 0.2s
23.		800 / 1000Hz 0.5s each (1Hz)
24.		250Hz - 1200Hz at 12Hz
25.		500Hz - 1200Hz at 0.33Hz
26.		2400Hz - 2900Hz at 9Hz
27.		2400Hz - 2900Hz at 3Hz
28.		500 - 1200Hz, 0.5s/ 0.5s OFF x 3/1.5s OFF (AS1670 Evacuation)
29.		800Hz - 970Hz at 9Hz
30.		800Hz - 970Hz at 3Hz
31.		800Hz, 0.25s ON / 1s OFF
32.		500Hz - 1200Hz, 3.75s / 0.25s OFF (AS2220)

Note: Tones 1, 4, 5 and 7 are EN54-3 approved tones.

Sounder duration

As default, wireless sounders will automatically switch off after 30 minutes to conserve battery life. For continuous uninterrupted operation (*until switched off by the control panel*), follow the steps below.

From access level 3 (*as previously shown on page 16*), press the  button until the screen displays:

```
View System Status
Maintenance/Test
Device Options
→WZM Settings
```

Press the  button and the screen will display:

```
→Panel Type
Sounder Options
Device Indicator
```

Press the  button and the screen will display:

```
Panel Type
→Sounder Options
Device Indicator
```

Press the  button and the screen will display:

```
→Default Tone Select
Sounder Duration
Sounder Activation
Pulsed Output
```

Press the  button and the screen will display:

```
Default Tone Select
→Sounder Duration
Sounder Activation
Pulsed Output
```

Press the  button and the screen will display:

```
→30 Mins Auto Off ✓
Continuous
```

Press the  button and the screen will display:

```
30 Mins Auto Off ✓
→Continuous
```

Press the  button and the screen will display:

```
Sounder Duration
Set To
Continuous
```

Sounder activation method

As default, wireless sounders will only operate upon activation of the WZM's fire input. For 'immediate mode', so that sounders also operate upon the activation of a wireless device, follow the steps below.

From access level 3 (*as previously shown on page 16*), press the  button until the screen displays:

```
View System Status
Maintenance/Test
Device Options
→WZM Settings
```

Press the  button and the screen will display:

```
→Panel Type
Sounder Options
Device Indicator
```

Press the  button and the screen will display:

```
Panel Type
→Sounder Options
Device Indicator
```

Press the  button and the screen will display:

```
→Default Tone Select
Sounder Duration
Sounder Activation
Pulsed Output
```

Press the  button until the screen displays:

```
Default Tone Select
Sounder Duration
→Sounder Activation
Pulsed Output
```

Press the  button and the screen will display:

```
→Panel Mode
Immediate Mode
```

Press the  button and the screen will display:

```
Panel Mode
→Immediate Mode
```

Press the  button and the screen will display:

```
Sounder Activation
Set To
Immediate Mode
```

Pulsed output

As default the PULSED OUTPUT for the fire and the fault relays is set to latched. Upon an activation, the relay will remain latched in alarm until the WZM is reset. To alternatively pulse into alarm for a pre-defined period of time (range from 5-60 seconds) before automatically clearing, follow the steps below.

From access level 3 (*as previously shown on page 16*), press the  button until the screen displays:

```
View System Status
Maintenance/Test
Device Options
→WZM Settings
```

Press the  button and the screen will display:

```
→Panel Type
Sounder Options
Device Indicator
```

Press the  button and the screen will display:

```
Panel Type
→Sounder Options
Device Indicator
```

Press the  button and the screen will display:

```
→Default Tone Select
Sounder Duration
Sounder Activation
Pulsed Output
```

Press the  button until the screen displays:

```
Default Tone Select
Sounder Duration
Sounder Activation
→Pulsed Output
```


Press the  button and the screen will display:

```
→Fire Relay- LATCH
Fault Relay- LATCH
```

Press the  and  buttons, until the screen displays the required relay type: In this example, the fault relay has been chosen.

```
Fire Relay- LATCH
→Fault Relay- LATCH
```

Press the  button and the screen will display:




Fault Relay
00 LATCH
Secs ⬅ / ➡ To Select

Press the  and  buttons, until the required time is displayed:
In this example, 20 seconds has been chosen.



Fault Relay
20 Seconds
Secs ⬅ / ➡ To Select

Press the  button and the screen will display:



Fire Relay- LATCH
➔ Fault Relay- 15
⬇

Note: the same options are available for the fire and fault relays.

Device indicator operation

This feature is only available when the ‘Panel Type’ is set to ‘Addressable’. As default, the device LED indicators are switched ‘Off When Silenced’ (upon receipt of a silence command signal from the control panel). Alternatively ‘Off When Reset’ can be selected (where the device LED indicators switch off upon the receipt of a reset command signal from the control panel, by following the steps below.

From access level 3 (as previously shown on page 16), press the  button until the screen displays:

View System Status
Maintenance/Test
Device Options
→WZM Settings

Press the  button and the screen will display:

→Panel Type
Sounder Options
Device Indicator

Press the  button until the screen displays:

Panel Type
Sounder Options
→Device Indicator

Press the  button and the screen will display:

→Off When Silenced ✓
Off When Reset

Press the  button and the screen will display:

Off When Silenced ✓
→Off When Reset

Press the  button and the screen will display:

Fire Status
Turned Off
When Reset

Device signal levels

From access level 3 (as previously shown on page 16), press the  button until the screen displays:

```
View System Status
→Maintenance/Test
Device Options
WZM Settings
```

Press the  button and the screen will display:

```
→Sounder.O/P Test
Device Signal List
Device Battery List
Edit Service Code
```

Press the  button until the screen displays:

```
Sounder.O/P Test
→Device Signal List
Device Battery List
Edit Service Code
```

Press the  button and the screen will display:

```
→Good Signal      08
Low Signal        00
No Signal         00
More>
```

Press the  &  buttons to highlight the required signal category.

```
→Good Signal      08
Low Signal        00
No Signal         00
More>
```

Press the  button to select the required category and the device signals can be viewed, by pressing the  &  buttons.

```
Z01 A08          80dB
Dual Detector
First Floor Landings
GOOD Signal      
```




Note: It is important that all devices have GOOD signal levels to ensure the maximum robustness of wireless signalling.

If a device does not achieve a good signal level, for further guidance refer to the 'How to improve device signal levels' section within the SmartCell WZM Programming Guide (MK067).

Test devices

Every device should be function tested, to ensure correct functionality.



- Smoke detectors should be tested using a smoke detector tester and in accordance with local codes of practice.
- Heat detectors should be tested using a heat detector tester and in accordance with local codes of practice.
- Call Points should be tested in accordance with local codes of practice.
- Sounder operation should also be tested in accordance with local codes of practice.
- Input / Output devices should also be tested in conjunction with associated 3rd party equipment and in accordance with local codes of practice.

Congratulations

Your SmartCell WZM should now be successfully installed.



Notes

SmartCell

www.mysmartcell.com

The information contained within this literature is correct at time of publishing. EMS reserves the right to change any information regarding products as part of its continual development enhancing new technology and reliability. EMS advises that any product literature issue numbers are checked with its head office prior to any formal specification being written.