


7511 VAULT RELAY PUSH



The Alarm function is activated by pressing both side buttons together.

The event will cause the relay contacts to OPEN for a period of approximately 4 seconds or until the buttons are released.

The Alarm memory latch will set with the RED led "ON" and the GREEN LED "OFF", and will remain so till reset.

The alarm relay can be caused to latch by connecting the internal jumper to the "ON" position. The relay will remain latched with open contacts, until manually reset using the right hand side button.

The alarm memory latch is reset by pressing the Green side button. In the clear mode the "RED" LED "OFF" and "GREEN" LED "ON".

A 10 ohm resistor is connected in series with the relay contacts to limit the maximum current, to protect the relay contacts from damage. These contacts are Normally Closed.

