
FireCell



RADIO CLUSTER COMMUNICATOR QUICK START GUIDE






RCC Quick Start Guide Iss 6 - MK138 AJM

www.emsgroup.co.uk




Step 1 Identify RCC Locations:

If a radio survey has already been carried out, the survey will detail the recommended location of the RCCs and also their communication path back to the Hub.




The recommended distance between metal objects from the aerial is 600mm. The recommended distance to any other electrical equipment is 2 metres.




Step 2 Identify Mains Entry Location:

Mains cable entry can be made on either side of the unit. This is made possible with rotation of the power supply allowing maximum installation flexibility. The RCCs backup battery can also be relocated to the other side of the unit. See the FireCell Instruction Pack for more information.




Step 3 Prepare RCC Box:

Open the unit and carefully remove the inner PCB. The mains cable entry can now be made. See entry points below:



Step 4 Fix the RCC to the Wall:

The unit can now be fixed to the wall. The PCB and connecting lead can now be carefully re-inserted. See the RCCs fixing positions below:



Step 5 Apply Power to RCC:

Connect the Mains supply and power the unit. The battery should also now be connected.

Step 6 Log on RCC to the Hub:

If the system has been supplied fully programmed, the installation of the RCC is now complete.

If the system has been supplied unprogrammed, the RCC will now require programming to the Radio Hub. It is recommended that the RCCs ident number is recorded along with the RCCs radio communication path back to the Hub. See the FireCell Instruction Pack for more information.

