


Combined Sounder/Detector/Visual Indicator with European tones Installation Guide



Part No Product Description

FCX-174-001	Multisensor Smoke Detector Only
FCX-175-001	Heat A1R Detector Only
FCX-176-001	Heat CS Detector Only
FCX-177-001	Optical Smoke Detector Only
FCX-194-000	Sounder/Detector Base Only
FCX-194-200	Sounder/Detector/Red Visual Indicator Base Only

CPR

2 2 3

41

See the Specification section for compliance information.

1 Pre Installation



Installation must conform to applicable local installation codes and should only be installed by a fully trained competent person.


- Ensure that the device is installed as per the site survey.
- The use of a non-metallic spacer should be considered if mounting the device on to a metal surface.
- Do NOT Press the Log On button on a pre-programmed device, as this will cause communication with the Control Panel to be lost. Should this happen, delete the device from the system and add it back on.



3 Fix Mounting Plate


Remove the mounting plate from the wireless module by turning it anticlockwise.

- Use both mounting holes to ensure a firm fixing.
- Use suitable fasteners and fixings.




5 Optional Device Locking

- To lock the detector into the wireless module, remove the cut out (shaded) section as shown.
- To unlock the detector, insert a 1.5mm Allen key and lever the Allen key towards the outside of the device and turn the detector anticlockwise to release.
- The wireless module can also be locked into the mounting plate by removing the shaded section shown and fitting a 5/16 Phillips pan head screw.



– 63mm —

2 Components




4 Power Device

• When fitting / replacing batteries; observe correct polarity, using only specified batteries.

(1) Dust Cover (2) Detector (3) Wireless Module (4) Mounting Plate

• Set switch 1 to the ON position to power the device. See the configuration section for other available switch settings.



6 Configuration

The device's loop address is configured within the menu structure of the Radio Hub.

• Refer to the programming manual (Doc Ref: MK98) for full programming information.




Free to download from www.emsgroup.co.uk

Configuration Continued

Device Powering/Sounder Volume (Set on Wireless Module)

Switches 1-2 on the 4 way switch are used to power the device and to change the sounder volume.

Default Setting: Supplied unpowered with high sounder volume.



SWITCHES 1 & 2	DEVICE POWERED?	SOUNDER VOLUME	
ON ON	\checkmark	HIGH 97dB A (+/- 1dB)	
ON OFF	\checkmark	LOW 71 dB A (+/- 1dB)	
OFF ON	×	HIGH 97dB A (+/- 1dB)	
OFF	×	LOW 71 dB A (+/- 1dB)	

(Set on Wireless Module)

Sounder Tone *

Switches 3-4 on the 4 way switch are used to configure the sounder tone.



SWITCHES 3 & 4	PRIMARY TONE	TONE TYPE	TONE DESCRIPTION / APPLICATION	SECONDARY TONE	TONE TYPE	TONE DESCRIPTION / APPLICATION
ON GFF 3 4	13		1200Hz – 500Hz @	1		970Hz
OFF 3 4	1		970Hz	<u>1</u> 8		2400Hz
ON 3 4	5		970Hz, 0.5s/ 630Hz,	4		970Hz 1s OFF / 1s ON
OFF 3 4 OFF	7		500 – 1200Hz,	1		970Hz

Default Setting: Primary Tone 7

🚺 IMPORTANT

- Remove dust cover before use.
- The device should be tested upon installation and in accordance with local requirements.
- Testing should only be carried out by a fully trained competent person.
- The Manufacturer recommends regular functional testing of at least once per annum or in accordance with local codes of practice.
- Cleaning and repairs must be undertaken by the Manufacturers authorised representative.
- Do not open the case to clean inside the detector.

Specification			Regula
Operating Temperature	-10°C to 55°C		Manufactur
Storage Temperature	5°C to 30°C		Year of manufactur
Humidity	Up to 95% non-condensing	ļ	Certification
Supply	3x AA Alkaline (Panasonic LR6AD Powerline / Varta 4006 Industrial) & 3x C Alkaline (Panasonic LR14AD		Certification body
CAUTION!	Powerline / Varta 4014 Industrial)		CPR Certificate DOP
result in poor performan			Approved to
IP Rating	IP23	T T	
Operating Frequency	868MHz	T T	
Output Transmitter Power	Auto adjusting 0 - 14 dBm (0 - 25 mW)	-1 -1 - -1	
Sounder Output	97dB(A) @ 1m (as dispatched). Low setting reduces volume by 26dB.		
	Refer to the sounder data document (MK187) for full details. <i>Free to download from www.emsgroup.co.uk</i>		
Dimensions	146mm (Ø) x 53mm (D) (No detector) 146mm (Ø) x 89mm (D) (with smoke detector) 146mm (Ø) x 94mm (D) (with heat detector) 146mm (Ø) x 100mm (D) (with multisensor detector)		European Union directives
Weight	0.70kg (with detector)		
Location	Type A: For indoor use		X

Regulatory Information

anufacturer	EMS Ltd. Technology House, Herne Bay, Kent, CT6 8JZ, United Kingdom
ear of anufacture	See devices serial number label

uracture	See devices ser	la namber laber		
ification	C € 20 [1]	CE10 [2][3]	CE12 ^[4]	
ification /	0905			
	Coo part listing	for accoriated produ	i et e i	

See part listing for associated products:
[1] 0905-CPR-202126 [2]0359-CPR-0015,
[3]0359-CPR-0017 & [4]0359-CPR-0121

 d to See part listing for associated products: EN54-3:2001. Incorporating Amendments Nos. 1 and 2. Fire detection and fire alarm systems. Part 3: Fire alarm devices -Sounders. [4]

EN54-7:2001. Incorporating Amendment No. 1. Fire detection and fire alarm systems. Part 7: Smoke detectors - Point detectors using scattered light, transmitted light or ionization. [1][3]

EN54-25:2008. Incorporating corrigenda September 2010 and March 2012. Fire detection and fire alarm systems. Part 25: Components using radio links. [4]

 Iropean
 EMS declares that the radio equipment type FireCell Combined

 ion
 Sounder/Detector/Visual Indicator is in compliance with

 Directive
 Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

 www.emsgroup.co.uk
 Kernel Combined

