




Wireless Beacon Installation Guide



Part no **Description**

FC-171-001 White Wireless Sounder Base Only FC-171-002 Red Wireless Sounder Base Only FC-323-CA1 White Ceiling Beacon Only FC-323-CA2 Red Ceiling Beacon Only FC-323-WA1 White Wall Beacon Only FC-323-WA2 Red Wall Beacon Only

CPR

[2]

[1]

[1]

[1]

See the Specification section for compliance information.


1 Pre installation



Installation must conform to applicable local installation codes and should only be installed by a fully trained competent person.

- Ensure that the device is installed as per the site survey.
- The use of a non-metallic spacer should be considered if mounting the device on to a metal surface.
- Do NOT Press the Log On button on a pre-programmed device, as this will cause communication with the Control Panel to be lost. Should this happen, delete the device from the system and add it back on.
- This device contains electronics that may be susceptible to damage from Electrostatic Discharge (ESD). Take appropriate precautions when handling electronic boards.

2 Components





1 Beacon, 2 Wireless module, 3 Battery retaining plate, 4 Mounting plate

3 Fix mounting plate

Remove the mounting plate by turning the device ANTICLOCKWISE, to release it from the mounting plate.


- Use both fixing positions to ensure a firm fixing.
- Use suitable fasteners and fixings.





4 Power device


- Unclip the battery retaining plate from the wireless module.
- When fitting / replacing batteries; observe correct polarity, using only specified batteries.
- Connect the power jumper across the PIN header.




Once powered, reassemble the device.

5 Optional device locking

- To lock the beacon into wireless module, remove the cut out section as shown.
- To unlock the device, insert a 1.5 mm allen key to depress the locking clip and turn anticlockwise to release.





6 Configuration

The device's loop address is configured within the user interface's menu

Refer to the programming manual for full programming details.

FireCell = MK98 Fusion = TSD062WZM = TSD143



Free to download from www.emsgroup.co.uk

Configuration continued

Beacon flash rate (set on beacon)

Switch 2 on the two way switch is used to configure the beacon flash rate. Switch 1 is not used on this product.


Default setting: primary tone 5

Audio monitoring (Set on wireless module)

The device has an audio self test feature which is not used on this version of product.

Both switches should be OFF as shown.

Default setting: Audio monitoring disabled









Specification

Operating temperature -10 to +55 °C

Storage temperature 5 to 30 °C

Humidity 0 to 95% non-condensing

Supply 3x AA alkaline (*Panasonic LR6AD Powerline* /

Varta 4006 Industrial) 3x C alkaline (Panasonic LR14AD Powerline / Varta 4014 Industrial)

CAUTION!

Fitting of an incorrect battery type invalidates the product certification and may result in poor performance.

IP rating IP54

Operating frequency 868 MHz

Output transmitter power Auto adjusting 0 to 14 dBm (0 to 25 mW)

Signalling protocol X

Beacon element voltage 17 to 60 VDC operating at 18 VDC

Beacon element current max. 40 mA at 1 Hz flash rate

Flash rate 0.5 Hz / 1 Hz (selectable)

Beacon category / coverage C-3-15 / 337 m³ (ceiling mounted variant)

W-3.1-11.3 / 396 m³ (wall mounted variant)

Dimensions (Ø x D) 120 x 145 mm

Weight 0.65 kg

Location Type A: For indoor use

Regulatory information

Manufacturer KGS Manufacturing Poland Sp. z o.o.

Ul. Kolejowa 24. 39-100 Ropczyce, Poland

Year of manufacture See devices serial number label

Certification

0905 0905 UK 7



DoP number 0359-CPR-00292

Approved to See part listing for associated products:

EN54-23:2010. Fire detection and fire alarm systems. Part 23: Fire alarm devices. Visual alarm devices. [1]

EN54-25:2008. Incorporating corrigenda September 2010 and March 2012. Fire detection and fire alarm systems. Part 25: Components using radio links. [2]

European Union Directives

EMS declares that this device is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.emsgroup.co.uk

*

2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see www.recyclethis.info

Dispose of your batteries in an environmentally friendly manner according to your local regulations.